

CONFIDENTIAL

This document contains confidential material. This material cannot be shared except with persons that have a valid business reason to read this content. You are personally responsible to ensure recipients of this document are aware of information handling guidelines.

Service schematics

Lumia 532

RM-1034

Lumia 532

Dual SIM

RM-1031

RM-1032



IMPORTANT

This document is intended for use by authorized Microsoft service centers only. Please use the document together with other documents such as the Service Manual and Service Bulletins.

Version information

While every effort has been made to ensure that the document is accurate, some errors may exist. Please always check for the latest published version for this document.

v1.0 - 30.01.2015

-First approved version.

Contents

- 1 Front page
- 2 PM8110, MSM8212, Power, Side keys, USB
- 3 MSM8212, Memory, Accelerometer, SIM(s)
- 4 MSM8212, Display/Touch, Camera(s), Flash, Proximity
- 5 MSM8212, Audio, BT/WLAN/FM
- 6 RF Transceiver, GPS
- 7 Component finder Top
- 8 Component finder Bottom (RM-1031)
- 9 Component finder Bottom (RM-1032)
- 10 Component finder Bottom (RM-1034)

Version differences

This document will cover following releases:

Lumia 532 Dual SIM, RM-1031, Board: 4nb_50a (Dual band)
 Lumia 532 Dual SIM, RM-1032, Board: 4nb_50c (Quad band)
 Lumia 532, RM-1034, Board: 4nb_50b (Quad band)



Send feedback

- Recommend Change in KICS
- Rate this page in KICS
- e-mail careacademy@microsoft.com





